



Get A Killer Tool Box Without Killing Your Budget

Features and Benefits:

- •Full double walled construction making for a stronger box which resists the constant pounding of weight and vibration.
- •Stiffeners are added between the walls to reduce stress on the box and keep the drawers from sagging.
- •Close to 15,000 cubic inches of space.
- •Drawers are made of 20 gauge steel.
- •Welded lock tabs on the back of each drawer.
- •Casters are fastened to the roll cab using weld nuts so they won't loosen over time.
- •Drawer edges are hemmed to double thickness so they are extra stiff,



KRB2006PQR — 26" 6-Drawer Roll Cab (red), also available — KRB2006PQP — 26" 6-Drawer Roll

Cab (Blue)

See page 2 for specifications and feature shots and page 3 for warnings.

KRB2055PQR — 26" 5-Drawer Top Chest (red), also available — KRB2055PQP — 26" 5-Drawer Top Chest (Blue)



Country of Origin - Canada

CE - Not Required







KRB2006 and KRB2055 Feature shots and specifications



Drawer pulls are 3/4" deep for extra finger room when pulling.



Welded lock tabs on back of drawer add security and durability.



Reinforced panel engineering keeps the box strong and straight for the lifetime of the cabinet.



Casters are secured with weld nuts for superior strength and load rating.



Double-wall design for a more rigid tool box.

KRB2006

26" 6-Drawer Roll Cab	Drawers	Width	Depth	Height	Cu. Inches	Sq. Inches	
Overall	6	26	19.8	38"	9,568	2,247	
4" wide	5	21.4	17.5	3.59	6,722	1,873	
8" wide	1	21.4	17.5	7.6	2,846	375	
Net weight 170 lb	Ball slide capacity 100 lbs per drawer						

KRB2055

				Cu.	Sq.
Drawers	Width	Depth	Height	Inches	Inches
5	26	14.72	17.2	4,444	1,818
4	22.3	13.14	1.85	2,168	1,172
1	22.3	13.14	3.12	914	293
	25.8	13.67	3.86	1,361	353
		5 26 4 22.3 1 22.3	5 26 14.72 4 22.3 13.14 1 22.3 13.14	5 26 14.72 17.2 4 22.3 13.14 1.85 1 22.3 13.14 3.12	5 26 14.72 17.2 4,444 4 22.3 13.14 1.85 2,168 1 22.3 13.14 3.12 914

Net weight 91 lb **Ball slide capacity 100 lbs per drawer**





KRB2006 and KRB2055 Warnings



WARNINGS

Units can tip or strike you.



- •Do not open more than one loaded drawer at a time.
- •Keep children away.



- •Close lid and lock drawer and doors before moving. •Apply brakes on locking casters when not moving unit.
 - •Do not step in or on drawers.



- Secure units together with fasteners.
- •Read instruction Manual.

Tipping of storage unit or unit striking you can cause injury.



Unit's edges can cut or pinch.

•Do not pull; push to move. •Wear gloves when lifting by edges.



•Keep feet and fingers clear of edges when stacking, hanging or moving units.

Unit edges can cause injury.



Risk of tripping.

•Do not use extension cords with power drawer outlets. Tripping can cause injury.



Risk of electric shock and fire.

- •Do not remove the ground connection.
- •Do not expose to rain, snow, or wet conditions.
- •Do not operate with damaged cord or plug.
- •Replace damaged cord or plug immediately. Electric shock or fire can cause injury.



Risk of explosion.

- •This equipment should not be located in a recessed area or below floor level.
- •Flammable fuel or vapors can ignite.
- •Power drawer has internal arcing or sparking parts.
- Do not expose to flammable vapors.
- •Power drawer components to be mounted at least
- 460mm (18 inches) or more above the floor.

Explosion or flame can cause injury.

